



INSTRUCTIONS

TETHER CHOKE™, SINGLE/TWIN ARM

CODE

Single arm → 101368

Twin arm → 101369

MAX LOAD

↳ 20KG / 44LBS

NLG ID

Scan the orange tags on compatible NLG products to access detailed product info, certification and installation videos.

NOTE

The Tether Tape™ is used for positioning and is not load bearing in this setup

01



Pass the loop end around the handle or body of the tool. Ensure the securing arm is facing away from the trigger if using a powered tool. Pass the V Ring through the loop end to securely cinch around the tool.

02



Cut a length of Tether Tape™ (1 length for each arm, long enough to wrap around the tool at least 5 times. Remove the plastic backing strip.

03



Wrap the Tether Tape™ around the securing arm(s), leaving the webbing catch exposed. Ensure that the Tether Tape™ is firmly stretched during application, as this activates the self-fusing technology.

04

Test the tether point before putting the tool into use.