

LANYARD TERMINATION INSTRUCTIONS

ROTOBINER™

CATEGORY

→TOOL LANYARD

MAX LOAD ⇒SEE LABEL

NLG ID

Scan the orange tags on compatible NLG products to access detailed product info, certification and installation videos.

01



Rotate the gate 90 degrees and drawback to open.

02



Clip the open rotabiner/carabiner onto the tether or anchor and release the gate. It will automatically close and lock on release

03



Check that it is securely fastened at both ends with a gentle tug on the lanyard.