



ROTOBINER™

CATEGORY

↳ TOOL LANYARD


MAX LOAD

↳ SEE LABEL

NLG ID

Scan the orange tags on compatible NLG products to access detailed product info, certification and installation videos.

01



Rotate the gate 90 degrees and drawback to open.

02



Clip the open rotabiner/carabiner onto the tether or anchor and release the gate. It will automatically close and lock on release

03



Check that it is securely fastened at both ends with a gentle tug on the lanyard.



CHOKE

CATEGORY
↳ TOOL LANYARD

MAX LOAD
↳ SEE LABEL

NLG ID
Scan the orange tags on compatible NLG products to access detailed product info, certification and installation videos.

TIP
Where there is a spring loaded toggle on the choke, this is only to stop the choke from loosening.

01



Pass choke loop through the captive handle or hole, or through the anchor D ring.

02



Pass the other end of the lanyard through the loop.

03



Pull the lanyard through the open loop to create a cinch.

04



Check that it is securely fastened at both ends with a gentle tug on the lanyard.