



CHOKE

CATEGORY
↳ TOOL LANYARD

MAX LOAD
↳ SEE LABEL

NLG ID
Scan the orange tags on compatible NLG products to access detailed product info, certification and installation videos.

TIP
Where there is a spring loaded toggle on the choke, this is only to stop the choke from loosening.

01



Pass choke loop through the captive handle or hole, or through the anchor D ring.

02



Pass the other end of the lanyard through the loop.

03



Pull the lanyard through the open loop to create a cinch.

04



Check that it is securely fastened at both ends with a gentle tug on the lanyard.