



## INSTRUCTIONS

# ADJUSTABLE WRISTBAND

### CODE

↳101365

### MAX LOAD

↳3KG / 6.6LBS

### NLG ID

Scan the orange tags on compatible NLG products to access detailed product info, certification and installation videos.

### TIP

The wristband can be used as an anchor around a structure. [example: scaffold tube]

01



Open the wristband by peeling up the velcro strap and slacken loop.

02



Pass hand through the loop.

03



Pull down strap to required fit and attach to velcro. Position D ring to underside of wrist.

04

Check the wristband is secure.