

INSTRUCTIONS

TETHER RING™

CODE

NLG ID

installation videos.

Small \rightarrow 101466 Medium \rightarrow 101273 Large \rightarrow 101275

Scan the orange tags on compatible

NLG products to access detailed

product info, certification and

MAX LOAD →1KG / 2.2LBS

_____ TIP

For easy installation use a pair of needle nose or split ring pliers.

01

02



Select the correct size of Tether Ring[™] that allows enough room for lanyard connection. For shaped tools, ensure that it is small enough not to slide off either end.

Use pliers to separate the Tether Ring[™] and thread onto the tool, in the same manner as a key ring.

03



Test the tether point before putting the tool into use.